

---

## Aluminium Balustrade Installation

The Chatterton aluminium balustrade panels are installed in between the aluminium handrail and the aluminium bottom rail. Installation is made

simple with self tapping hexagon head screws

Installation of the top rail to the verandah posts is done with the assistance of the handrail fixing brackets. Check the rail is installed at the correct height, usually one

metre from the floor to the top of the rail. This is done first then the verandah panels are installed underneath the top rail. You may find it easy to then set the bottom rail in order to fit the panels to. You will need to trim the panels to fit, unless using a panel requiring spaces between them. It is important to use a spirit level

The continuous panel will require to be carefully trimmed, working from one end to the other end trimming the last panel. Starting in the centre of the span and working to each end is often an option, however it is important not to have small sections on the ends