


**Post Capital Bases**

\* Please be aware there are two types of post capital bases

**Post Capital slides over post**

Available in sizes:

- 90x90mm
- 100x100mm
- 120x120mm
- 150x150mm



Installation is made simple

1. Place over top of post
2. Use screws on either side of capital to secure to post

**Post Capital sits on top of the post**

Available in sizes:

- 100x100mm
- 125x125mm
- 150x150mm
- 200x200mm

\* This post capital suits timber posts



Installation is made simple

1. Remove the screws from the lid of the casting
2. Drill some screw holes through the bottom casting
3. Put the screws through the bottom holes and screw down tightly into the post